

Наименование изделия Блендерный наборНомер модели IR-5509Серийный номер HGY08092020

Дата продажи « » _____ 20 г.

М.П.
торгующей
организации**Условия гарантии:**

Уважаемый покупатель! Вы приобрели изделие, произведенное под ТМ "IRIT". Данный талон дает Вам право на устранение дефектов изделия в авторизованных сервисных центрах в течение 12 месяцев со дня продажи. Все условия гарантии осуществляются в соответствии с действующим законодательством. Проследите, чтобы данный талон был правильно заполнен и имел печать торгующей организации.

В случае возникновения неисправностей техники в течение гарантийного срока, Вы можете обратиться в авторизованный сервисный центр, адреса и телефоны которых указаны на обороте гарантийного талона. Сервисный центр произведет ремонт или выпишет акт, в случае невозможности ремонта данного изделия. На основании этого акта Вы можете обратиться в торгующую организацию, в которой было приобретено изделие, для обмена.

После истечения гарантийного срока сервисные центры, указанные в гарантийном талоне, всегда готовы предложить Вам свои услуги по ремонту бытовой техники "IRIT".

Гарантия не включает в себя периодическое обслуживание, установку, настройку и чистку изделия, порядок которых изложен в Инструкции по эксплуатации.

Гарантийное обслуживание не производится при:

- несоблюдении правил эксплуатации изделия, установленных Инструкцией по эксплуатации;
- утрате гарантийного талона;
- ремонте неуполномоченными на это лицами, а также при других, непредусмотренных инструкцией вмешательствах;
- механических повреждениях, возникших по вине потребителя;
- использовании изделия в целях, для которого оно не предназначено;
- внесение изменений и/или исправлений в текст данного талона.

С внешними данными и комплектацией товара ознакомлен: _____ (подпись)

Сохраняйте гарантийный талон и чек контрольно-кассовой машины на изделие. Без предъявления данного талона, его неправильном заполнении и/или отсутствии печатей торгующей организации на талоне и корешках, претензии к качеству не принимаются.

<p>КОРЕШОК К ТАЛОНУ № irit®</p> <p>Модель: _____</p> <p>Дата продажи « » _____ 20 г.</p> <p>Наименование <u>Блендерный набор</u></p> <p>Модель <u>IR-5509</u></p> <p>Сер. номер <u>HGY08092020</u></p> <p>Ф.И.О. клиента _____</p> <p>Телефон _____</p> <p>Адрес _____</p> <p>М.П. торгующей организации</p>	<p>КОРЕШОК К ТАЛОНУ № irit®</p> <p>Модель: _____</p> <p>Дата продажи « » _____ 20 г.</p> <p>Наименование <u>Блендерный набор</u></p> <p>Модель <u>IR-5509</u></p> <p>Сер. номер <u>HGY08092020</u></p> <p>Ф.И.О. клиента _____</p> <p>Телефон _____</p> <p>Адрес _____</p> <p>М.П. торгующей организации</p>
---	---

irit®

ИНСТРУКЦИЯ

по эксплуатации

Manual Instruction



Блендерный набор

Hand Blender Set

IR-5509

irit®

IR-5509

IR-5509

irit®

Descriptions

1. Motor
2. Attachment with blade
3. Whisk
4. Chopper bowl

**Safety measures**

- Read the instruction carefully before using the appliance.
- Before the first connection, make sure if the voltage indicated on the appliance is the same as the supply voltage in your home.
- To avoid electric shock and other injuries, do not immerse body of appliance in water or other liquids.
- Always unplug the appliance in case of operating failure, after the use and before cleaning.
- Do not use the appliance, if the power cord, plug or other part is damaged.
- In case of breakdown – apply to authorized service center.
- Do not use the appliance outdoors. It is for household use only.
- Do not leave operating appliance without supervision.
- Use accessories and spare parts, provided by the manufacturer only.
- Avoid contact of power cord and sharp corners or any hot surfaces.
- Keep out of the reach of children.
- **Attention!** Blades are very sharp, be careful.
- Always unplug the appliance, before assembling, re-assembling, cleaning and storage.
- All the reparations must be made by authorized service center. Unqualified reparation may cause injuries and breakdowns.
- **Attention!** Whisk and chopper bowl can not be used in microwave oven.
- Make 5 minute break after 1 minute use.
- Uninterrupted operation can cause motor overheat and breakdown.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Use

- Before assembling, make sure the appliance is unplugged.
- Before first use, clean the body with a soft damp cloth and clean the nozzles with warm soapy water, let it dry.

- Set the attachment to the body, arrows on the body and attachment with blade must match together. Rotate the attachment anticlockwise as far as it can go.
- Plug in the appliance.
- Plunge the attachment into the liquid products.
- Press the button to choose the proper **Attachment with blades**
- Attachment with blades is used for whisking products, cooking soups, mayonnaises, dressings.
- Set the attachment to the body, arrows on the body and the attachment with blades must match together. Rotate the attachment anticlockwise as far as it can go.
- Plug in the appliance.
- Plunge the attachment into the liquid products.
- Press the button to choose the proper power. **Chopper bowl**

- The bowl is used for chopping products and mixing cocktails and other liquids.
- To make it operate, settle the removable blade inside the bowl, close the bowl with a cover by rotating it clockwise. Set the body above the cover, arrows on the body and cover must match together. Rotate the attachment anticlockwise as far as it can go.
- Plug in the appliance.
- After process is finished, unplug the appliance, rotate the body anticlockwise and take it out.
- **Choosing the power**
- By pressing button 1 or 2 you may set up the power you need, from lower to higher.
- You may use the attachment with blades, plunging it into any kind of reservoir.
- For better results use wider reservoir.
- Try to whisk not more than 400 ml of liquid at the same time (for whisking cream, recommended temperature of products is not higher than 4-8°C and fatness not less than 30%).
- Whisk together not more than 4 eggwhites.
- Move the attachment in the reservoir clockwise.

Clean and care

- Always unplug the appliance before cleaning.
- Power cord and the body must be never immersed into water.
- Blades may be cleaned under the water flow.
- Clean the body with a soft damp cloth and clean the removable parts with warm soapy water.
- Do not use abrasive materials for cleaning.

The date of manufacture is marked on the packaging

The importer retains his right to make changes in appearance and completeness of the item without preliminary notification to the customer.

For household usage only.

Do not leave unattended!

Technical parameters:
Power: 200 W
Voltage: 220-240V/50Hz
Service life is 2 years
Made in China



