4.ACTION PROGRAMMING

1)Press the "Action programming" button until hear a "beep"sound.

2)Up to 50 functions can be programmed. You can
forward/backward,turn left/right,twist waist,hand up/down,
music,gymnastics,song,story.

3)Press the "Action programming" button to perform
programmed fuctions again.

5.SONG

Press the "song" button,the robot will sing a song with
moving.
There are 10 different songs in total.

6.STORY

Press the "story" button, the robot tells a story, four stories in all.

Walk or glide backward

Turn right or turn left

Walk or glide forward

SMART DIALOGUE

When the robot is in standby mode, the voice dialogue function will be turned on automatically.
When receiving the following command, the robot will automatically respond.

VOICE COMMAND	ROBOT RESPONSE
1.Hello	Hello guys+ Left hand up
	Miikalila+ Spread out its arms
	You are so cute+ Turn around
2.You are so cool!	Makasilo+ Twist waist
	Haha， The same to you+ turn around
	Thank you+turn around
3.Where are you from	It's a secret.+walking
	Venus Pologulu+walking
	A distant Planet. +walking
4.I love you	Abubabu, lalalala~
	I love you,too
	Abubu
	OK +do sports with music
5.Let's do sports!	Abubabu, lalalala +do sports with music
	Come on! +do sports with music
6.Go forward	Walk forward
	Yes,sir+Slide forward
	Walk backward
7.Go backward	Yes,sir +Slide backward
	Slide to the left
8.Turn left	Got it+Turn left
	Slide to the right
9.Turn right	Got it+Turn right
	Twist waist with music 1
10.Twist your waist	Twist waist with music 2
	Moving shoulders
11.Move your shoulders	Moving shoulders
	No problem+song 1
12.Sing a song	Aha,It's show time+song 2
	Bulubabulagu+song 3
	Great! Here we go!+dance 1
13.Dance for me	Music+dance 2
	Hah,Good idea+dance 3
	Bye-bye.+ Go into sleep mode
14.Goodbye	OK, See you.+ Go into sleep mode
	Salala+ Go into sleep mode
	Hu~~Go into sleep mode