

CAMERA CLIMBING CAR



App Operation Instructions

App Download

1. Scan the code to download WiFi UAV mobile software.
(Android sweep code and wait for the URL to open the Android software with this browser.)



Android



Apple


Operating Instructions

1. WIFI Connection

Method 1 Turn on the product power switch. Go to the phone settings and open "WIFI", find the WIFI hotspot of the device from the WIFI list and click connect until it is successfully connected. (Note: Normally, the WIFI connection without password is selected by default.) Open the APP and click the WiFi UAV icon to enter the real-time interface.

Method 2 Turn on the product power switch, open the APP click WiFiUAV icon, enter the interface, click the icon in the upper left corner to connect WIFI, then click Back to return to the interface. (As shown in the picture on the right)

Click this icon to connect to WIFI (Note: Under normal circumstances the default is to choose a WIFI connection without a password)



(Method 2)


2. Setting Interface

Operation setting interface, if you are not used to the operation after entering the real-time control surface, you can adjust in this interface.

Maneuvering Mode choose left-handed mode or right-handed mode according to the mode you are used to.

Waiststick Mode fixed position can show the interface, easy to manipulate, hide the variable position, can screen real presentation.

Language Mode choose the language type.



Upgrade Self-service upgrade system available

Help Detailed explanation of interface icon functions

3. Click on the start, you can enter the remote control car control interface (the following picture) need to click on this interface and then OFF, before you can start to control



4. Icon Description

	Return to previous level		Photo button		Video button		Follow the track		30% increase in travel speed
	Folders for photos and videos		Medium speed/high speed		Gravity Induction		Turn on/off		Enlarge the screen 50 times
	Can produce dynamic music video		Menu		Mirror flip photo		Gesture (not applicable)		3D split screen
	Headless (not applicable)		Lens calibration (not applicable)		Emergency stop (not applicable)				

5. MV (after entering MV, you can add various functions)

	Mosaicable		The screen can be divided into several screens		Screen rotation
	Make the screen watermarked		You can add a variety of music		Various filters can be added



6. Once setup is complete, you're ready to play!