

hoco.

premium product

BS31


烁音运动蓝牙音箱

说明书

很高兴您购买BS31 烁音运动蓝牙音箱，我们希望您将享受它给您带来的乐趣！

Make something you love.

蓝牙音箱说明图：



- ① 电源键
- ② 音量+/下一曲
- ③ 音量-/上一曲
- ④ MFB【多功能键】
- ⑤ AUX
- ⑥ TF卡
- ⑦ Micro-USB
- ⑧ LED

规格参数

喇叭单元：53MM, 4Ω/3Wx1
 频率响应：60Hz~18000Hz
 蓝牙规格：V4.2
 支持协议：A2DP, AVRCP, HSP, HFP
 传输范围：10米
 传输频率：2.4GHz

充电电压：DC 5V
 充电时间：约2.0小时
 通话时间：3小时以上
 音乐时间：3小时 (80%)
 尺寸：86x86x44mm

功能介绍

长按电源键开机，蓝灯持续闪烁，进入配对模式，打开需连接设备蓝牙功能，搜索“HOCO BS31”，点击连接，蓝灯长亮，并听到提示音，完成配对及连接。

按键控制

蓝牙模式操作

- 暂停键可播放或暂停音乐
- 音量减键 短按可上一曲，长按减声音
- 音量加键 短按下一曲，长按可加声音

温馨提示：当机器在播放的过程中有出现报警的声音，请连接充电器进行充电（充电器的充电电压：5V，建议充电电流为0.5A）

LED指示

蓝色：播放音乐时指示灯显示蓝色
红色：充电时长亮红色，充满电时红灯熄灭

注意事项

请将本机放置于干燥通风处，避免受潮、雨淋，进水；
请勿将本机暴露在温度过高或温度过低的地方以及强磁场环境；
请勿使用挥发性液体或其他有机溶液擦拭产品表面；
请勿将本产品接触任何尖锐的物体，避免造成划痕和损毁；
请勿尝试私自拆机、自行修复、改装本机，严禁强力摔打。

hoco.

premium product

BS31


BS31 Bright sound sports wireless speaker

Manual

Thank you for purchasing BS31 Bright sound sports wireless speaker! Hope that you will have fun using it!

Make something you love.

Wireless Speaker Description:



- ① Switch
- ② Sound volume (+)Next
- ③ Sound volume (-)Previous
- ④ MFB【Multi-functional button】
- ⑤ AUX
- ⑥ TF
- ⑦ Micro-USB
- ⑧ LED

Specifications

Speaker unit: 53MM, 4Ω/3Wx1
 Frequency response: 60~18000Hz
 Wireless specification: V4.2
 Transmission range: 10m
 Transmission frequency: 2.4GHz
 Supported Protocol: A2DP, AVRCP, HSP, HFP
 Product Size: 86x86x44mm

Charging voltage: DC 5V
 Charging time: about 2.0h
 Call time: above 3h
 Music time : 80% volume 3 hours

Features

Long press power button to turn on speaker, the blue light flashes, enter the pairing mode, turn on the Wireless function of the device to be connected, search"HOCO BS31", confirm connection, the blue light is on constantly, with tone notification, pairing and connection are completed

Wireless mode operation

- Pause button to play or pause music
- Volume down short press for the previous track, Long press to reduce the sound
- Volume up short press for next track, Long press to increase sound

Reminder:

When there is a warning sound during playback , it is low power prompt , please charge the speaker (charging voltage: 5V, charging current : 0.5A)

LED Indicator

Blue: The indicator light is blue when playing music
Red: The indicator light is red while charging , and the red light is off when fully charged.

Attention

- Please place the speaker in the dry and ventilated place, avoid moisture and rain water;
- Please do not expose this speaker to the place where the temperature is too high or too low, and the strong magnetic field;
- Do not use volatile liquid or other organic solvents to wipe the surface of the speaker;
- Do not touch the speaker with any sharp objects, to avoid scratches and damage
- Do not attempt to disassemble, repair and modificate this speaker, no strong shaking and no drop.

深圳浩酷科技发展有限公司

产品名称

物料名称 说明书

设计师

材质工艺 128克双铜 黑白印刷

技术要求

标记	版本	变更内容	年、月、日	制作人	审核	批准
	A1	第一次印刷	2019/06/05	王卫星	苏华超	